


- Release clamp -2- and unscrew screws -4- and -5-.
- Remove air deflector with exhaust gas recirculation pipe -3-.




- Release and pull off connector -1- and unscrew screw -2-.
- Remove knock sensor 1 - G61- -3-.

Installing

Installation is carried out in the reverse order. When installing, observe the following:

- Install the engine cover
⇒ [“3.1 Removing and installing engine trim panel”, page 26](#).
- Install air filter housing
⇒ [“4.2 Removing and installing air filter housing”, page 220](#).
- ◆ Tightening torque: 20 Nm



1.5 Removing and installing Hall sender - G40-

Removing

- Remove engine cover
⇒ [“3.1 Removing and installing engine trim panel”, page 26](#).
- Release and pull off connector -1- and unscrew screw -2-.
- Remove hall encoder - G40- -3- upwards.

Installing

Installation is carried out in the reverse order. When installing, observe the following:

- Install the engine cover
⇒ [“3.1 Removing and installing engine trim panel”, page 26](#).


Tightening torques - summaries of components



Note

Replace bolts / nuts that are tightened at an angle of rotation, as well as replacement components after removal.

- ◆ ⇒ [“1.1 Summary of components - Glow plug system”, page 281](#)



1.6 Removing and installing the engine speed sender - G28-

Special tools and workshop equipment required

- ◆ Assembly tool - T10118-
- ◆ Socket size 4 - T10370-



Removing

- Remove the noise insulation ⇒ General body repairs, exterior; Rep. gr. 66 ; Noise insulation; Summary of components - noise insulation .
- Pull off connector -1- using assembly tool - T10118- .



Note

To unlock the plug connections without the assembly tool - T10118- , use a screwdriver to press the plug on the engine speed sender and simultaneously raise the release button with a thin wire hook.

- Unscrew screw -2-, remove engine speed transmitter - G28- .

Installing

Assembly is carried out in the reverse order. When installing, observe the following:

- Insert the engine speed sender - G28- so that the lug -3- engages in the guide on the sealing flange -4-.
- Tighten screw -2- and insert plug -1-.



Tightening torques - summaries of components



Note

Replace bolts / nuts that are tightened at an angle of rotation, as well as replacement components after removal.

- ◆ ⇒ [“1.1 Summary of components - Glow plug system”, page 281](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by ŠKODA AUTO A. S. ŠKODA AUTO A. S. does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by ŠKODA AUTO A. S. ®