



pillar and D-pillar trim ⇒ General body repairs, interior; Rep. gr. 70 ; Interior trim panels; Removing and installing D-pillar trim panel .

- Remove connector from the window aerial (where fitted).
- Remove glass residue down to the adhesive cement.
- Cover the painted surfaces along the window with textile adhesive tape.
- Cut back the adhesive cement e.g. with electrical cutting tool - V.A.G 1561/A- to approx. 1 mm thickness.
- Suction vacuum glass residues in the vehicle with a vacuum cleaner.

Removing undamaged window



WARNING

It is essential to wear protective goggles and gloves when cutting hardened PUR adhesive sealing material and when handling the cutting cord.

- Remove top C-trim panel ⇒ General body repairs, interior; Rep. gr. 70 ; Interior trim panels; Removing and installing C-pillar and D-pillar trim ⇒ General body repairs, interior; Rep. gr. 70 ; Interior trim panels; Removing and installing D-pillar trim panel .
- Remove connector from the window aerial (where fitted).
- Cover the painted surfaces along the window with textile adhesive tape.



Note

- ◆ *In order to facilitate the insertion of the cutting cord, apply lubricant (e.g. detergent) on the outer side of the window flange.*
- ◆ *In order to avoid damage to the paintwork, the cord ends must be inserted correctly into the needle from below, at the same time a protective foil should be glued in the area of the pierced cement.*
- ◆ *Check several times the correct fitting of the cutting cord during assembly.*