

6 Air deflector

⇒ [“6.1 Removing and installing centre vent”, page 115](#)

⇒ [“6.2 Removing and installing the right/left side vent”, page 116](#)

⇒ [“6.3 Removing and installing rear centre vent”, page 117](#)

⇒ [“6.4 Removing and installing the rear footwell vent”, page 117](#)

⇒ [“6.5 Removing and installing for front duct under centre console”, page 118](#)

⇒ [“6.6 Removing and installing the footwell vent on the driver's side”, page 118](#)

⇒ [“6.7 Removing and installing the footwell vent on the front passenger side”, page 119](#)

⇒ [“6.8 Removing and installing air guide for defroster vent”, page 119](#)

⇒ [“6.9 Removing and installing air guide for centre vent in the dash panel”, page 120](#)

⇒ [“6.10 Removing and installing exhaust ventilation for passenger compartment”, page 120](#)

⇒ [“6.11 Checking exhaust ventilation for passenger compartment”, page 121](#)

⇒ [“6.12 Removing and installing fresh air intake”, page 121](#)

6.1 Removing and installing centre vent

Special tools and workshop equipment required

- ◆ Release tool - T30111-

Removing

- Remove the display unit for infotainment ⇒ communication; Rep. gr. 91 ; Infotainment system; indicator unit for display and control unit, front information removal and installation



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by ŠKODA AUTO A. S. ŠKODA AUTO A. S. does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by ŠKODA AUTO A. S.