



## 66 – Exterior equipment

### 1 Wheelhouse liner

⇒ ["1.1 Removing and installing the front wheelhouse liner", page 102](#)

⇒ ["1.2 Removing and installing the rear wheelhouse liner", page 102](#)


#### 1.1 Removing and installing the front wheelhouse liner

##### Removing

- Remove wheel ⇒ Chassis; Rep. gr. 44 .
- Remove screws -2- (1.5 Nm).
- Remove wheelhouse liner -1-.

##### Install

- Installation is carried out in the reverse order.



#### 1.2 Removing and installing the rear wheelhouse liner

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by ŠKODA AUTO A. S. ŠKODA AUTO A. S. does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by ŠKODA AUTO A. S. ©

##### Removing

- Remove wheel ⇒ Chassis; Rep. gr. 44 .
- Removing body-bound rivet -3-.
- Remove screws -2- (1.5 Nm).
- Remove wheelhouse liner -1-.

##### Install

- Installation is carried out in the reverse order.

