




## Installing



### Note

*Check the expanding nuts - 2 - for damage, replace them if necessary.*



- Insert wheelhouse liner - 1 - in the wing.
- Install screws -2-. Tightening torque: 2 Nm.

## 7.2 Removing and installing the rear wheelhouse liner

### Removing